


MICRO INVERTER

HYX-M1200-SW-NA-LV

HYX-M1200-SW-LV



Carefully read this user manual before using the product.
Read and save these instructions.

© **ZHEJIANG HYXI TECHNOLOGY CO., LTD. All rights reserved.**

This document cannot be copied fully or partially, transferred, or distributed in any form without the prior written permission of ZHEJIANG HYXI TECHNOLOGY CO., LTD (hereinafter referred to as "HYXI").

TRADEMARKS



and other HYXI trademarks are the trademarks or registered trademarks of HYXI. All other trademarks mentioned herein are the properties of their respective owners.

Contents

- About the Manual 1
 - Overview 1
 - Scope of Application 1
 - For Readers 1
 - Use of the Manual 1
 - Use of Symbols 2
- 1 Safety Precautions 3
 - 1.1 Safety Instruction 3
 - 1.2 Symbols on the Label 4
 - 1.3 Radio Wave Interference Statement 4
- 2 Product Introduction 5
 - 2.1 Photovoltaic On-Grid System 5
 - 2.2 Microinverter 5
 - 2.3 3-in-1 Microinverter System 6
 - 2.4 Communication Technology 6
 - 2.5 Product Features 6
 - 2.6 Inverter Size and Termnial Instruction 7
- 3 Installation 8
 - 3.1 Microinverter System Installation Accessories 8
 - 3.2 Installation Tools Requirement 8
 - 3.3 Installation Procedures 9
 - 3.3.1 Making a T-Junction Bus 9
 - 3.3.2 Microinverter Installation 10
 - 3.3.3 Connecting Microinverter with T-junction 11
 - 3.3.4 Connecting PV module 11
 - 3.3.5 Drawing Installation Map 12
 - 3.3.6 Operation and Power-On 12
- 4 Troubleshooting 13
 - 4.1 Status Indication and Error Reporting 13
 - 4.1.1 Start Indicator Light 13
 - 4.1.2 Operation Indicator Light 13
 - 4.2 Alarm Code 13
 - 4.3 On-Site Inspection (Qualified Installers Only) 16
- 5 Maintenance 17
 - 5.1 Routine Maintenance 17

- 5.2 Microinverter Replacement..... 17
- 5.3 Storage and Transportation.....18
- 5.4 Disposing of the Microinverter.....18
- 6 Human-Computer Interaction19**
 - 6.1 Installing the App.....19
 - 6.2 APP Configuration19
- 7 Appendix.....20**
 - 7.1 Technical Parameter..... 20
 - 7.2 Installation Map21
 - 7.3 Contact Information 22

About the Manual

Overview

This manual provides the user with product information, storage, detailed installation and troubleshooting.

To ensure the proper installation and use of the product and its superior performance, before handling, installation, operation and maintenance of the product, please read the operating instructions in detail and follow all safety precautions in the instructions.

Scope of Application

This manual is intended for the following device:

- HYX-M1200-SW-NA-LV
- HYX-M1200-SW-LV

For Readers

This manual is intended for professional technicians who need to install, operate and maintain the product and for users who need to check the product parameters.

All installation operations must be carried out by professional technicians and only by professional technicians.

Use of the Manual

Please read the manual carefully before using the product, the content of the manual will be updated and corrected, but it is inevitable that there is a slight discrepancy or error with the actual product. Users should refer to the actual product purchased and obtain the latest version of the manual by downloading from www.hyxipower.com or through sales channels.

Use of Symbols

To ensure user safety and property protection during product use, relevant information is provided and highlighted with the following symbols.

DANGER

- Indicates a high potential hazard that, if not avoided, could result in death or serious injury.

WARNING

- Indicates a moderate potential hazard that could result in death or serious injury if not avoided.

CAUTION

- Indicates a low potential hazard which, if not avoided, could result in moderate or minor injury.

NOTICE

- Indicates a potential risk which, if not avoided, could result in the equipment not functioning properly or in property damage.

1 Safety Precautions

HYX-M1200-SW-NA-LV and HYX-M1200-SW-LV series microinverters can efficiently convert direct current into alternating current that meets the requirements of the power grid and feed the power into the power grid. They are designed and tested in strict accordance with relevant national safety standards.

The installation, trial operation, operation and maintenance of the inverter must comply with relevant safety regulations. Incorrect operation or use will endanger:

- Life and personal safety of operators or third parties.
- Other property of the operators or third parties.

Important Safeguards and Warnings

To ensure the installation and operation safety of inverter and reduce the risk of electric shock, this manual uses the following safety symbols to mark some danger indications and safety precautions. Safeguards and Warnings in the specific operation process will also be explained in detail in the corresponding chapters.

This manual contains important instructions to be followed when installing and maintaining the microinverter. Users should read this manual thoroughly before installing or debugging the microinverter.

For safety, the technicians responsible for the installation, operation and maintenance of this microinverter must have corresponding qualifications, received relevant training and master relevant skills. Installation, operation and maintenance must strictly follow the instructions contained in this manual.

1.1 Safety Instruction

- Only qualified professionals can install and replace the microinverter.
- The electrical installation of microinverter must comply with local electrical regulations.
- Read all instructions and warning signs in this manual before installing and using the microinverter.
- To avoid scalding, do not directly contact the shell of the microinverter, and the shell temperature can reach 80 °C .
- Before disconnecting the microinverter from the solar module, the AC side power grid must be disconnected first.
- If the microinverter does not work normally, contact after sales services of HXYI. Unauthorized destruction or opening of the microinverter will not be covered by warranty.

1.2 Symbols on the Label

Symbol	Description
	Caution When the device is running, do not step within 0.2 m of its periphery.
	High Voltage The high voltage generated by microinverter can endanger life.
	High Temperature The microinverter will generate heat during operation. Do not touch the metal surface.
	Reading Manual Read the user's manual carefully before installation, operation and maintenance.
	CE The microinverter meets EU low voltage standard.
	Discarding Do not treat the microinverter as domestic garbage.

1.3 Radio Wave Interference Statement

After testing, this microinverter meets the requirements of CE and EMC and is free from electromagnetic interference. This product might cause electromagnetic interference if it is improperly installed.


You can turn off the microinverter and then start it again to detect whether the radio is interfered by the inverter. If the inverter interferes with radio, take the following measures to eliminate the influence:

- Relocate the receiving antenna away from other devices.
- Increase the distance between the microinverter and the antenna.
- Use metal or concrete materials to separate the microinverter from the antenna.
- Consult a local supplier or skilled radio technician.

2 Product Introduction

2.1 Photovoltaic On-Grid System

The on-grid system diagram of HYX-M1200-SW-NA-LV series microinverter is as follows:



2.2 Microinverter


HYX-M1200-SW-NA-LV series are 3-in-1 microinverters, which can connect four photovoltaic modules. They are module-level photovoltaic inverters with module-level monitoring function.

The whole system consists of two parts, photovoltaic on-grid power generation system and photovoltaic monitoring system. photovoltaic on-grid power generation system includes photovoltaic modules, microinverter, AC cable and other accessories. Microinverter is the core product of photovoltaic power generation system, and it has independent maximum power point tracking (MPPT) control, which can maximize the energy output of the whole solar array and maximize the power generation performance of photovoltaic system no matter how the array is arranged or when it encounters unsatisfactory conditions such as shadow occlusion, dirt accumulation, illumination deviation or mismatch in practical application.

In addition, microinverters do not require the consistency of photovoltaic modules like central and series inverters. Each microinverter transformer can be easily mounted on the rack below the panel. The panel-side low-voltage DC line can be directly connected to the microinverter, eliminating the danger of high-voltage DC voltage.


Remote monitoring platform:

The operating data and working status of the inverter are transmitted through the wireless router, and the user is provided with module-level monitoring through the Web or App application to realize remote operation and maintenance.



2.3 3-in-1 Microinverter System

The DC side can choose a microinverter series according to the number of connected photovoltaic modules. As shown below:



This manual mainly introduces HYXI 3-in-1 microinverter series.

This series of HYX-M1200-SW-NA-LV has outstanding performance in 3-in-1 series, with an output power up to 1200VA. Each microinverter can be connected to four photovoltaic modules. It has independent MPPT and module-level data monitoring functions, high power generation, easy and convenient maintenance features.

2.4 Communication Technology


HYX-M1200-SW-NA-LV microinverter series adopts a new wifi wireless communication solution.

Wi-Fi communication solution: It operates in the 2.4GHz frequency band, and the transmission distance is weaker than the Sub-1G frequency band. It does not need additional communication equipment and can directly communicate with HYXI Cloud.

2.5 Product Features

- Maximum output power 1200W.
- Module-level MPPT, the rated MPPT efficiency reaches 99.8%.
- IP67 enclosure, 6000V surge protection for higher reliability.

2.6 Inverter Size and Termnial Instruction



A: AC Branch Connector B: Antenna C: DC terminal

3 Installation

Each microinverter is installed on a mount just below the solar module panel.

The low-voltage DC line on the panel side of the solar module can be directly connected to the microinverter, but it must be protected from direct sunlight, rain, snow, ultraviolet rays, etc.

It is recommended to leave a gap of at least 50mm around the microinverter casing to ensure ventilation and heat dissipation.

 **CAUTION**

- The instructions in the manual must be followed when moving and placing the device.
- Mishandling of equipment may result in minor, serious injury or contusion.
- The cooling fins of the device must be left uncovered to ensure sufficient internal cooling of the device.

3.1 Microinverter System Installation Accessories


Image	Description	Image	Description
	T-junction cable		T-junction bus end plug
	M8*25 bolt (Self preparation)		T-junction removal tool
	T-junction bus connector		T-junction branch line port protection cover

*The above accessories are not included in the product package and need to be purchased separately.


3.2 Installation Tools Requirement



Wire stripper



Hydraulic plier



Philips screwdriver




Multimeter




Marker



Cable Tie



Measuring tape



Allen wrench



Dust mask



Goggles



Insulated shoes




Protective gloves

3.3 Installation Procedures


3.3.1 Making a T-Junction Bus

Step 1: Prepare several sections of T-junction connecting wires according to the number of microinverters to be installed on site.


Step 2: Removing the T-junction cable at the end.




Use the T-knot removal tool to remove the lower cover.



Loosen the inner screw, unscrew the nut, and remove the cable.




Install a T-junction bus end plug at the end of the T-junction.




Insert the lower T-junction cover back into place and make sure it is secure.


Step 3: T-junction and bus connection




Prepare the AC cable by stripping the ends.



Insert the AC cable into the T-junction connector at the correct hole position.




Tighten the screws, and then the nuts.



Insert the lower T-junction cover back into place, making sure it is secure.

Step 4: Secure the T-junction cable

Put the T-junction connecting wire on the guide rail and fix it with cable tie.


**⚠ CAUTION**

- Nut tightening torque: $2.5 \pm 0.5 \text{ N} \cdot \text{m}$, Screw tightening torque: $0.8 \pm 0.1 \text{ N} \cdot \text{m}$, Do not over-tighten, Do not damage the sealing ring in the T-junction connector during assembly and disassembly.
- Do not contact T-junction bus connectors with water directly.
- Use a professional tool to uninstall the T-junction bus connector.

3.3.2 Microinverter Installation

Step 1: Mark the installation position of the microinverter on the bracket According to the layout of the photovoltaic modules.


Step 2: Fix the microinverter on the bracket with M8*25 screw, then lock the screw. (* The inverter indicator panel should face the bracket)

**⚠ CAUTION**

- Install the microinverter and all DC connections under the PV module to avoid direct sunlight, rain and snow, etc.
- Leave $\geq 20 \text{ mm}$ space between Microinverter and PV module for Ventilation and heat dissipation.
- Screw tightening torque: $9 \text{ N} \cdot \text{m}$, Do not over-tighten.
- Do not carry AC cables during transportation.

3.3.3 Connecting Microinverter with T-junction


Insert the output AC feeder connector of the microinverter into the T-junction bus connector until hearing a "click" sound. Ensure that the installation is tight.



3.3.4 Connecting PV module

Step 1: Install the PV module above the microinverter.

Step 2: Connect the DC output cable of the PV module with the input side of the microinverter.




⚠ CAUTION

- Ensure that the output current and voltage of the PV modules are consistent with the inverter.
- Operating DC voltage range of the PV module must be within the input voltage range of the microinverter.
- The maximum Voc of the PV module shall not exceed the maximum input voltage of the microinverter .
- DC output power of PV module shall not exceed 1.5 times that of the AC output power of the microinverter.

3.3.5 Drawing Installation Map

Tear off the serial number label of microinverter and affix serial number label on the corresponding position according to the installation map for quick identification during maintenance.



3.3.6 Operation and Power-On

Step 1: Close the main Grid circuit breaker.

Step 2: Close the AC circuit breaker of each microinverter branch, and the system will automatically generate power after about 2 minutes.

Step 3: Set up monitoring system on HYXI Smart PV Cloud Platform.

4 Troubleshooting

Only qualified professionals can implement the following troubleshooting operations when the microinverter solar system is not working properly.

4.1 Status Indication and Error Reporting

4.1.1 Start Indicator Light

When the DC side of the microinverter is powered on for the first time :

- The green lights blink briefly indicateing startup success.
- The red lights blink briefly indicateing startup failure.

4.1.2 Operation Indicator Light

Light	Status	Meaning	Light	Status	Meaning
Green	Fast flashes (1s gap)	Normal	Red	Light on	Ground error
	Slow flashes (3s gap)	Communication error		Fast flashes (1s gap)	Error
	Slow flashes (5s gap)	PV input error		Fast flashes (2s gap)	AC error

4.2 Alarm Code

Fault code	Fault description	Solution
3073	PLL Phase lock	1. It may be a short-time grid abnormality when occurs occasionally. It will resume work without manual intervention after the grid is normal. 2. Check AC connection when the fault occurs frequently. 3. Contact the distributor if the cable connection and power grid are normal.
3074 3075	PV1-PV3 Circuit undervoltage PV1-PV3 Circuit overvoltage	1. If the input voltage is too high, ensure that the input voltage of PV module is not higher than the maximum input voltage of the microinverter. 2. If the input voltage is low or zero, ensure that the component is properly connected. 3. Contact the distributor If the component voltage is within the normal range.
3076	PV1-PV3 over-current	1. If the input current is too high, ensure that the input voltage of PV module is not higher than the maximum input voltage of the microinverter. 2. Contact the distributor If the component voltage is within the normal range.

Fault code	Fault description	Solution
3091 3092	PV-1 & PV-2 terminal connection fault PV-3 terminal connection fault	1. Check if the terminal connect to the PV module. 2. Check if the port is properly connected if connection is fine.
3082	Island protection	1. Occasionally, it may be a short-term power grid abnormality. When the power grid is normal, it will resume work without manual intervention. 2. If all the microinverters in the power station have frequent islanding alarms, please contact the power bureau to confirm whether there is indeed an islanding phenomenon and solve it. 3. If the problem still cannot be solved, please try to contact the equipment manufacturer or dealer.
3083	Insultation resistance	1. Check whether the wiring on the input side of the microinverter is normal. 2. Check whether the modules (junction box) are normal.
3084	Device overheating	1. Check whether the ambient temperature of the microinverter exceeds the maximum allowable temperature. 2. If the ambient temperature exceeds the allowable temperature, please improve the installation environment. If the environment is normal, please contact the dealer or equipment manufacturer.
3086	The grid voltage fluctuates too much instantaneously	1. Occasionally, it may be a short-term power grid abnormality. When the power grid is normal, it will resume work without manual intervention. 2. If it occurs frequently, please confirm whether the grid voltage is normal. If the whole station alarms, please contact the local power bureau to solve the problem or adjust the instantaneous fluctuation limit of the grid voltage through the monitoring platform after obtaining the consent of the power bureau.
3087 3088 3090	EEPROM data corruption EEPROM data corruption Flash data corruption	1. Occasionally, and the microinverter works normally without manual intervention. 2. It keeps appearing and cannot be recovered, the microinverter cannot work normally, Please contact your dealer or device.

Fault code	Fault description	Solution
3097	PV1- PV3 Primary side hardware overcurrent	1. If the input DC current is too high, please ensure that the input photovoltaic module current is not higher than the maximum input current of the microinverter. 2. If the module current is within the normal range for three days and the microinverter does not work, please contact the dealer or equipment manufacturer.
3098 3099 3100	PV1-PV3 absorption capacity overvoltage Inverter bridge 1 hardware overcurrent Inverter bridge 2 hardware overcurrent	1. If the input DC voltage is too high, please ensure that the input photovoltaic module voltage flow is not higher than the maximum input voltage of the microinverter. 2. If the module voltage is within the normal range for three days and the microinverter does not work, please contact the dealer or equipment manufacturer.
3094	Remote shutdown	1. Confirm whether the anti-backflow is enabled. 2. If the anti-backflow is not enabled, please contact the dealer or equipment manufacturer.
/	Firmware error	1. Please confirm whether the upgraded firmware is correct, and re-upgrade. 2. Please confirm whether the communication between the microinverter and the platform is normal, and re-upgrade when connected to the grid. 3. If the fault still exists, please contact the equipment manufacturer or dealer.
/	Low power generation	1. If it occurs occasionally, it may be a short-term power grid abnormality. When the power grid is normal, it will resume work without manual intervention. 2. If all the microinverters in the power station have frequent islanding alarms, please contact the power bureau to confirm whether there is indeed an islanding phenomenon and solve it. 3. If the problem still cannot be solved, please try to contact the equipment manufacturer or dealer.

4.3 On-Site Inspection (Qualified Installers Only)

If the microinverter fails, please troubleshoot according to the following steps:

- Step 1:** Verify whether the grid voltage and frequency are within the range specified in the technical parameter table of the user manual.
- Step 2:** Check the connection to the grid. Disconnect the AC side first, then the DC side. When the inverter is still working, it is forbidden to disconnect its DC side connection. Reconnect the DC side and observe whether the indicator light flashes green briefly three times.
- Step 3:** Check the connection of each microinverter in the AC branch, and confirm whether each microinverter is powered by the public grid.
- Step 4:** Make sure that each AC circuit breaker is functioning normally and is in a closed state.
- Step 5:** Check the connection between the microinverter and the DC side of the solar module.
- Step 6:** Verify whether the DC voltage of the solar module is within the range specified in the technical parameter table of the user manual.
- Step 7:** If the problem persists, please call HYXI's customer support number.

Precautions for Routine Maintenance:

DANGER

- Do not attempt to repair the microinverter, if troubleshooting fails, return it to the factory for a replacement.
- Do not disassemble and repair the microinverter by yourself ! In order to ensure safety and insulation performance, users are prohibited from repairing internal parts.

CAUTION

- Do not replace the AC input harness (AC tap cable on the microinverter). If the wire is damaged, the equipment should be scrapped.
- Unless otherwise specified, the connection between the equipment and the power grid (disconnect the power switch) must be cut off during maintenance, while shielding or isolating photovoltaic modules.
- Do not use rags made of filamentous or corrosive materials to clean the equipment, otherwise it may cause corrosion or generate static electricity.
- Do not repair the product without authorization. Qualified parts must be used for maintenance.

NOTICE

- Each branch line should be equipped with a circuit breaker.

5 Maintenance

5.1 Routine Maintenance

- Only authorized personnel are allowed to perform maintenance operations and are responsible for reporting abnormal conditions.
- Wear personal protective equipment for maintenance operations.
- In normal operation, check the environment. Make sure that the environment does not meet the normal working requirements of the microinverter due to time changes, and ensure that the microinverter is not exposed to harsh weather and is not covered by foreign objects.
- Do not disassemble the microinverter or open the case for maintenance. In order to ensure safety and insulation integrity, the design of the microinverter does not allow the case to be opened for maintenance.

5.2 Microinverter Replacement

Replacement of miniature inverter The following steps shall be followed when replacing the failed miniature inverter converter on site:

- Step 1:** Disconnect the power supply of the branch circuit AC side circuit breaker.
- Step 2:** Disconnect the AC bus from the AC connector of the inverter.
- Step 3:** Remove the PV modules from the rack.
- Step 4:** Use the DC disconnect tool to disconnect the solar module and the DC connector of the microinverter.
- Step 5:** Use the AC disconnect tool to disconnect the AC connectors of the failed microinverter and the adjacent microinverter.
- Step 6:** Unscrew the fixing screws on the top of the microinverter and remove the device from the PV rack.
- Step 7:** Install the new microinverter on the rack, and observe the blinking of the indicator light when the DC line is reconnected.
- Step 8:** Connect the replacement microinverter's AC cables to the AC bus.
- Step 9:** Close the branch circuit breaker to verify the operation of the replacement microinverter transformer.

5.3 Storage and Transportation

In order to facilitate transportation and subsequent handling, HYXI packaging adopts a special design to protect each component. When transporting equipment, especially by road, protect components from severe moisture, shocks, vibrations, etc.

After receiving the microinverter, please check whether the outer packaging is damaged. If the outer packaging appears damaged, call the carrier immediately.

After unpacking, please check whether the appearance of the inverter is damaged and whether the accessories are complete. In case of damage to the microinverter or missing parts, please contact the supplier or authorized dealer of Hyxi to apply for repair/replacement and consult the relevant procedures. The storage temperature of the microinverter should be maintained between -40° C to +85° C.

5.4 Disposing of the Microinverter

If the device is no longer in use or needs to be stored for a long time, please make sure that the packaging is intact. Store the device in a well-ventilated indoor area that will not cause damage to device components.

- When restarting equipment that has been out of service for a long time, a complete inspection of the equipment must be carried out.
- Capacitors, modules and other components contained in the microinverter will pollute the environment, please dispose of them according to local regulations and laws.

6 Human-Computer Interaction

6.1 Installing the App

Method 1

Download and install the HYXI App through the following application stores:

- App Store (iOS)
- Google Play

Method 2

Scan the following QR code to download and install the HYXI App according to the prompt information:



6.2 APP Configuration

For specification configuration, please scan the following QR code to check HYXI APP_User Manual.



7 Appendix

7.1 Technical Parameter

Product Model	HYX-M1200-SW-NA-LV
Input (DC)	
Typical Module Compatibility [W]	360 - 600 *
Min./Max. MPPT Voltage [Vd.c.]	16 ~ 60
Max. Input Voltage [Vd.c.]	60
Start-Up Input Voltage [Vd.c.]	20
Max. Input Current [Ad.c.]	16
Max. Short-Circuit DC Input Current [Ad.c.]	20
Number of MPPT	3
Number of Strings per MPPT	1/2/1
Output (AC)	
Rated Output Power [VA]	1200
Rated Output Current [Aa.c.]	10
Rated Output Voltage [Va.c.]	120
Rated AC Voltage Range [Va.c.]	105.6 ~ 127.2
Rated Frequency [Hz]	50/60
Adjustable Output Frequency Range [Hz]	45 ~ 55, 55 ~ 65
Power Factor (Default/adjustable)	>0.99 / 0.8 leading...0.8 lagging
THDi [%]	< 3
Efficiency	
Rated MPPT Efficiency [%]	99.80
Night-Time Power Loss [mW]	< 60
General Data	
Operating Ambient Temperature [°C]	-40 to +65°C
Dimensions (W × H × D) [mm]	310 × 236 × 35.5
Ingress Protection	IP67
Cooling Concept	Natural cooling - no fans
Weight [kg]	5
Features	
Communication	Built-in Wi-Fi
Type of Isolation	High frequency transformers, galvanically isolated
Protection	
Input Reverse Connection Protection	YES
Output Overcurrent Protection	YES

Output Overvoltage Protection	YES
Anti-Islanding Protection	YES
Output Short-Circuit Protection	YES

7.2 Installation Map



Row: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100
Column: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

Layout Template



QR CODE											
No.											
QR CODE											
No.											
QR CODE											
No.											
QR CODE											
No.											
QR CODE											
No.											
QR CODE											
No.											
Paint black for North 			Azimuth: _____ Tilt: _____			Panel type: _____ Customer: _____			DMU		



6.2.51.18.00046_Ver1.3P-2020



7.3 Contact Information

If you have any questions about this product, please contact us.

In order to provide you with faster and better after-sales service, we need your assistance in providing the following information.

- Equipment model : _____
- Serial number of the equipment: _____
- Fault code / name: _____
- A brief description of the fault phenomenon: _____

Version: UM_HYX-M(1600-2000)-SW_V1.3-202609_EN

The manual is subject to change without notice while the product is being improved.



Zhejiang Hyxi Technology Co., Ltd.

Address: Building 1, No. 57 Jiang'er Road, Changhe Street, Binjiang District,
Hangzhou, Zhejiang Province, China

Website: www.hyxipower.com

E-mail: support@hyxipower.com